
# Smart work card

## Product instruction manual



## (Smart work card)

Please read the instructions carefully before using this product. This product is limited to the management of outdoor workers, work attendance, safety and intelligent management of team personnel, etc. It is prohibited to use for illegal activities that violate others' privacy such as detective and tracking.

## I. Product introduction

- **1.Name:** Smart work card
- **2.Feature:** Location query, electronic fence, SOS alarm, track playback. (All function are subject to the actual model)
- **3.Use:** This product is only used for outdoor staff management, work attendance, team personnel safety intelligent management, anti-loss and other legal purposes, prohibited all illegal uses.

## 4.Configuration list:

Number	Name	Quantity	Unit
1	Smart work card	1	set
2	Instruction manual, warranty card, certificate of qualification	1	set
3	Packing box	1	suit

Note: The above is the standard configuration list of the whole set of products. Accessories outside the above standard range of need to pay extra.

## 5.Matters needing attention:

- (1) Please keep the product away from extreme environments such as fire, high temperature and heat.
- (2) The shape and color of the equipment shall prevail.
- (3) It is strictly prohibited to disassemble, repair and modify products without permission.

## II. Specification parameter

### 1. Main specifications:

	Main specification
Master chip	4G module
Frequency	4G
Voltage	5V DC
Main interface	Type-C
Antenna	GPS ceramics and FPC

#### 2. Main functions:

	Main function
SIM	Nano
Battery	Polymer battery 1800mAh
Pilot lamp	Blue: Network light Green: GPS light Red: charging light
GPS	GPS+BD
G-sensor	Support
Positioning	Support
Playback	Support
Electronic fence	Support
Alarm message	Support
Battery display	Support
Double-talk	Support

## **III**. Installation method

#### 1.Procedure of use:

- Open the card slot and insert the SIM card that supports GPRS Internet access.
- Long press button 4 for 3 seconds to power on the device. When you see the indicator light on and the blue light blinking quickly, it indicates normal.
- Log in to the APP or website to check the location.

## 2.Light status (On the device):

(1) GPS singal light (Green)

Light	Status
Glowing	GSM no positioning
Flashing	GPRS normal communication/online

(2) Network light (Blue)

Light	Status
Glowing	No signal found or the SIM card is invalid
Flashing	Quick blink: The system is working properly Blinking slowly: The server is not connected or there is no GPRS network


#### (3) Charge light (Red)

Light	Status
Glowing	Charger or solar in charge
Extinguish	Charge complete

## IV. Common problem

Common problems	Reasons	Solutions
Weak signal	Test at areas where there are high buildings or under- ground parking lots, where radio waves cannotbe sent or eceived normally.	Move to good signal The regional location used
Platform map	GPS no location	go to outdoor place where signal is good
shows incorrect location	Inaccurate positioning	The GPS signal is weak in some areas, and the terminal will switch different positioning modes. The positioning difference is normal
The device and	Check whether the SIM card is normal	Contact your provider to check the status of your SIM card
platform are not connected	The SIM card is normal, but the terminal is offline	Please try to observe the status in the strong signal area

## V. Installation position



## Warranty Card

User Name		Telephone Number	
Address			
Model No.		IMEI(SN)	
Purchasing Date		Commercial invoice No	
Seller Name			
Seller Address			
Seller contace number			
<ol> <li>One year from the date of purchase, the non-human damage failure is guaranteed for one year;</li> </ol>			

- 2. Any of the following conditions is not covered by the warranty, but can be repaired if you pay the cost
- (1) Exceeding the warranty period;

(2) Damage caused by unauthorized disassembly or repair without the authorization of our company;

(3) immersed in water and the circuit board was burnt;

(4) Damage caused by improper installation, use, maintenance or storage;

- (5) damage of outer casing caused by the improper use;
- (6) The IMEI(SN) number of the product is torn or blurred;
- (7) The warranty card and product model No. not match, or the warranty card was altered;
- (8) Damage caused by force majeure.

### Certificate

	Certificate	
/	The product is approved to leave the factory after pass- ing the inspection	
	Model: Checker: Date:	

## Manufacturer

Company Headquarters: **Production base: Company Website:** Service Hotline: